



The dimensions in red give the distance from the PEXL sill level to the INVERT of the pipe.

The dimensions in green give the distance from the top of the PEXL to the top of the pipe.

The dimensions in black refer to the INNER diameter of the pipe.

PEXL

Dimensions in mm.
unless otherwise stated.

info@padmanstops.com.au
tel. 03 5874 5282

Padman Stops

Innovative Irrigation Solutions

© Padman Stops. This document is and shall remain the property of Padman Stops. Unauthorised use of this document in any form is prohibited. Patents may apply.